

FLUSHMATE® Genuine Replacement Parts

Installation:

Upper Supply

⚠ CAUTION: Pressure Vessel, to prevent injury turn water supply off and flush the unit prior to servicing.

To replace either type of upper supply, the procedure is the same.

Remember to turn the water off and flush the toilet.

1. Cut the hose as close to the upper supply fitting as possible.
2. Remove the upper supply by turning in a counter-clockwise direction. Remove clear gasket if found on threads.
3. Install the replacement upper supply in a clockwise direction. Do not over tighten.
4. Install replacement clamp on the hose. Install the hose all the way on the fitting. Tighten the clamp to secure the hose to the fitting. The clamp should be positioned in the center of the fitting.
5. Turn the water supply to the toilet back on. Check release.

